




1. Attach plastic feet to all 6 uprights, the narrow part of each slot pointing downwards.

2. With another person holding the uprights, place the 1830mm upright to the back and the 915mm to the front. Now tap the side beams in at the required positions for the worktop (slot 2 holes) and lower T bar level.

3. The face beams for the work top should be positioned in the top two holes of the 915mm upright.

4. Now insert the front to back deck support in the main work station level (2440mm wide workstation comes with 2 deck supports per level) and fit the left to right deck support which forms the T bar.

5. Add the 18mm thick shelf to the work top level.

6. Now position the 903mm uprights on top of the work top ready to tap in the side beams, position side beams as necessary.

7. Repeat for the face beams and then add the front to back deck support to both levels.
(2440mm wide workstation comes with 2 deck supports per level)

8. Add the 18mm thick chipboard panels to each shelf level.

9. Finally screw the plastic feet of the 903mm uprights down to the worktop with the 3.5 x 17mm chrome screws provided.

Tools Required

Rubber Mallet, Phillips Screwdriver

Safety Precaution

Two competent people wearing **safety gloves**, **safety shoes** and **protective eyewear** are recommended to undertake the assembly.



scan for more info